Tes

Drawn:

KJG

Checked:

GEF

Approved:

JHB

Date:

05/01/19

Scale:

1:6

Sheet: 1 of 2


T&S BRASS AND BRONZE WORKS, INC.

2 Saddleback Cove / P.O. Box 1088 Travelers Rest, SC 29690 Model No.

EC-3101-LMV

Item No.

Travelers Rest, SC: 800-476-4103 • Simi Valley, CA: 800-423-0150 • Fax: 864-834-3518 • www.tsbrass.com






T&S BRASS AND BRONZE WORKS, INC.

2 Saddleback Cove / P.O. Box 1088 Travelers Rest, SC 29690 Model No.

EC-3101-LMV

Item No.

Travelers Rest, SC: 800-476-4103 • Simi Valley, CA: 800-423-0150 • Fax: 864-834-3518 • www.tsbrass.com



 Label for Flow Control Switch Settings is Located on Inside of Back Cover.

Flow Control Switches are Located Inside Module Housing in Black Box Next to Battery Compartment.
*Switches are Set to DEFAULT Position:

- Auto Time Out = 15 Seconds
- Shut Off Delay = 1 Second
- Auto Flush = ÓFF

Remove (4) Screws and Back Cover to Access Switches.

- *Available Water Flow Control Selections:
 - Auto Time Out: 15 sec, 30 sec, 45 sec, 60 sec, 3 min, 20 min
 - Shut Off Delay: 1 sec, 10 sec, 15 sec, 30 sec
- Auto Flush (30 Seconds After Every 12 Inactive Hours): ON or OFF

Product Specifications:									Product Compliance:						
Chrome	Plated Bra I VR Aerat	ass Electroni		t: Wall Mount lodule w/ Inte				NSF 6	l - Se /2 (Lc .117.1	.18.1 / CSA ction 9 ow Lead Co I (ADA)					
Drawn:	KJG	Checked:	GEF	Approved:	JHB	Date:	05/01/19	Sc	ale:	NTS	;	Sheet:	2	of	2